




SK-FM4-216-ETHERNET

Hardware V1.0 / Documentation V1.3



Warranty and Disclaimer



The use of the deliverables (deliverables shall include, but not limited to, software, application examples, hardware, target boards, evaluation boards, starter kits, schematics, engineering samples of IC's etc.) is subject to the terms and conditions of Spansion LLC and its affiliates ("SPANSION") as set out below and in (i) the terms and conditions of the License Agreement and/or the Sale and Purchase Agreement and/or any other agreement under which deliverables have been delivered, (ii) the technical descriptions and (iii) all accompanying written materials.

1. Please note that the deliverables are intended for and must only be used for test applications in an evaluation laboratory environment.
2. The software deliverables are provided on an as-is basis without charge and are subject to alterations. It is the user's obligation to fully test the software in its environment and to ensure proper functionality, qualification and compliance with component specifications.
3. Regarding hardware deliverables, the following limited warranty shall apply:

Except as otherwise provided in the following paragraphs, for a period of one (1) year from date of shipment to customer ("Warranty Period"), SPANSION warrants the hardware deliverables (i) are free of defects in material and workmanship, and (ii) conform to SPANSION applicable data sheet specifications (available at www.spansion.com or upon request).

This warranty does not extend beyond the first purchaser of the deliverables. The liability of SPANSION under this warranty is limited, at SPANSION's option, solely to repair the deliverable, to send replacement deliverable, or to make an appropriate credit adjustment or refund in an amount not to exceed the original purchase price actually paid for the deliverable returned to SPANSION. SPANSION'S warranty obligations are conditioned upon the following: (a) SPANSION is promptly notified in writing by customer during the applicable warranty period of any defect or nonconformance in the deliverable, (b) customer obtains authorization from SPANSION to return the defective deliverable, (c) the defective deliverable is returned to SPANSION in accordance with SPANSION'S shipping instructions set forth below, and (d) SPANSION'S examination of such deliverable discloses to its satisfaction that any defect or nonconformance actually existed and was not caused by improper use or operation outside of the data sheet specifications for the deliverable, abuse, negligence, improper installation, accident, loss or damage in transit, or unauthorized repair or alteration by a person other than SPANSION. Customer shall ship such defective deliverable to SPANSION via SPANSION'S carrier, collect. Risk of loss will transfer to SPANSION when the defective deliverable is provided to SPANSION'S carrier. If customer fails to adhere to these warranty returns guidelines, customer shall assume all risk of loss and shall pay for all freight to SPANSION'S specified location. This warranty shall not apply to any deliverables that have been repaired or altered, except those which have been repaired or altered by SPANSION. The aforementioned provisions do not extend the original warranty period of any deliverable that has either been repaired or replaced by Seller.

THESE WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, NONINFRINGEMENT, AND ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION OR SAMPLE. SPANSION NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITIES. THE FOREGOING CONSTITUTES CUSTOMER'S SOLE AND EXCLUSIVE REMEDY FOR THE FURNISHING OF DEFECTIVE OR NONCONFORMING DELIVERABLES.

4. The following limitation of liability shall apply for all deliverables

EXCEPT FOR DAMAGES FOR BODILY INJURY OR DEATH, SPANSION SHALL NOT BE LIABLE FOR ANY INDIRECT, INCIDENTAL, SPECIAL, RELIANCE, OR CONSEQUENTIAL DAMAGES, RELIANCE DAMAGES, AND/OR PUNITIVE, OR EXEMPLARY DAMAGES, WHETHER ANY SUCH DAMAGES ARE BASED ON CONTRACT, TORT OR ANY OTHER LEGAL THEORY, AND WHETHER OR NOT SPANSION HAS BEEN INFORMED OF THE POSSIBILITY OF SUCH DAMAGES, AND NOTWITHSTANDING ANY FAILURE OF ESSENTIAL PURPOSE OF ANY LIMITED REMEDY.

REGARDLESS OF THE BASIS ON WHICH CUSTOMER IS ENTITLED TO CLAIM DAMAGES FROM SPANSION (INCLUDING FUNDAMENTAL BREACH, NEGLIGENCE, MISREPRESENTATION, OR OTHER CONTRACT OR TORT CLAIM), SPANSION ENTIRE LIABILITY IN ANY CALENDAR YEAR, REGARDLESS OF THE NUMBER OF CLAIMS, SHALL NOT EXCEED FIFTY PERCENT (50%) OF THE TOTAL AMOUNT PAID BY CUSTOMER TO SPANSION FOR THE DELIVERABLES SOLD IN SUCH CALENDAR YEAR.

5. Should one of the above stipulations be or become invalid and/or unenforceable, the remaining stipulations shall stay in full effect.


6. The contents of this document are subject to change by SPANSION without a prior notice, thus contact SPANSION about the latest one.

This board and its deliverables must only be used for test applications in an evaluation laboratory environment.



Overview

- [MCU Features, Board Features & Contents](#)
- [Test it](#)
- [The Hardware](#)
- [The Jumper Table / Jumper Default](#)
- [Board Power](#)
- [Software Examples & Tools](#)
- [Flash Programming](#)
- [JTAG / CMSIS-DAP](#)
- [IAR-Embedded Workbench](#)
- [KEIL µVision](#)
- [Workshops, Contacts & More](#)



■ Additional documents

- [Schematics](#)
- [Data sheet S6E2CC Series](#)
- [Peripheral Manual](#)
 - [Timer part](#)
 - [Analog part](#)
 - [Communication part](#)
 - [Ethernet part](#)
- [Flash programming manual](#)

Features of the S6E2CC Microcontroller



RC oscillator +/-2%

Clock Supervisor

Subclock (option)

Low Voltage Detector 2ch

SWJ/TPIU/ETM Debug Ports

MFS(UART/SPI/I²C) 16ch

Quad SPI

I²S

CAN (32 MSB) 2ch

CAN-FD 1ch

Ethernet MAC 10/100MBit

USB FS Host+Function 2ch

SD Card I/F

External Bus Interface
(SRAM, SDRAM, NAND, ..)

ARM Cortex-M4 – CPU

200MHz (max)

2.7-5.5V

MPU, FPU

T_a= -40°C to +105°C

FM4

Main CLK: 4MHz
SUB CLK: 32kHz
MAIN RC CLK: 4MHz
SUB RC CLK: 100kHz

Package:
LQFP144, LQFP176 , BGA192 , LQFP 216,

S6E2CC8H/J/L

FLASH 1MB SRAM 128K

S6E2CC9H/J/L

FLASH 1.5MB SRAM 192K

S6E2CCAH/J/L

FLASH 2MB SRAM 256K

OCU x 6ch

ICU x 4ch

ADT x 3ch

FRTim x 3ch

Multi Function Timer
3ch

Waveform
Generator

PPG 9ch

QDU 4ch

Base Timer
16ch

External IRQs
32ch + NMI

Dual Timer

DMA
8ch

Watch Counter

CRC

Resource
Pin Relocation

RTC
Y:M; h:m:s

12-bit ADC

32ch

12-bit ADC

Hardware Watchdog

DSTC 256ch

12-bit ADC


12-bit DAC
2ch

Features of the board




- Features of the SK-FM4-216-ETHERNET board:

- Microcontroller Spansion FM4 S6E2CCAL0A
- FM connect Ethernet: 1x IEEE802.3 Ethernet
- FM connect CAN: 2x CAN transceiver + 1x CAN-FD transceiver
- FM connect USB: 2x USB-Host (Type-A connector), 1x USB-Device (Type-B connector)
- FM touch: Slider using four ADC channels
- FM inverter. Motor-Control-Interface for e.g. SK-POWER-3P-LV2-MC
- FM color: Spansion S/W TFT interface
- Spansion flash memory S25FL164K, connected via quad SPI interface
- I²S audio interface
- SD Card interface
- 1x USB-to-serial converter (Type-B connector) using Spansion FM3 MB9AF312K
 - ♦ UART and on-board JTAG simultaneously (CMSIS DAP)
- Additional JTAG and Trace Interfaces each on a 20 pin-header
- 2x Spansion Multicon flexible serial interface supporting I²C, SPI, UART, and LIN
- User interface
 - ♦ Backlit LCD module
 - ♦ 5x pushbuttons (User buttons), potentiometer
 - ♦ 1x Reset-button, Reset-LED
- All 216 pins routed to pin-header
- On-board 5V and 3V voltage regulators to supply MCU with separate Power-LEDs
- 4x Power supply options: USB, USB-Device, JTAG or external 9V to 24V





- The SK-FM4-216-ETHERNET box contains
 - The SK-FM4-216-ETHERNET evaluation board
 - USB cable
 - Ethernet cable
 - CD: Documentation, software examples and development utilities
 - 1-page flyer



Test it



- The microcontroller on the SK-FM4-216-ETHERNET is already preprogrammed with an example application (<drive:>\Examples\sk-fm4-216-ethernet-tp_v12.srec).
 - Verify that jumpers JP75 and JP77 are set to 1-2 position and jumper JP76 is set to 3-4 position
 - Connect the SK-FM4-216-ETHERNET via DEBUG USB port (X2) with the PC
 - Verify that switch S1 is set to *RUN*
 - Press the *Reset*-button
 - The SK-FM4-216-ETHERNET's display will show a greeting message
 - Using the Up and Down pushbuttons will scroll through a menu on the LCD module
- Connect X3 (static IP address 192.168.1.20) to a PC or local area network
 - Configure your PC to an untaken IP address within the same subnet (such as 192.168.1.42)
 - Point your webbrowser to board's IP address (192.168.1.20)
- Install the USB Driver first <drive:>[drivers\driverinstaller.exe](#)
 - Check the availability for virtual COM port e.g. with Windows Device Manager
 - Open a serial terminal tool
 - e.g. Spansion Serial Port Viewer
<drive:>[tools\serialportviewer\setup.exe](#)
 - Settings 115200 baud, 8N1
 - More board tests are available via serial console





- You finished successfully the first tests


Congratulations!

- Now you will get more details about the SK-FM4-216-ETHERNET
- You will learn more about
 - The on-board features
 - How to program the Flash
 - How to start with IAR-Embedded-Workbench and KEIL µVision



Hardware

The Hardware (Top Side) – Function Overview





Jumper Settings – Power the starterkit




- The starter kit can be powered by
 - External power supply (9-24V)
 - Set jumpers JP75 and JP77 to position 1-2
 - Caution: Always set JP75 and JP77 horizontally, never vertically!**
 - Connect X1 to 8..24V DC power
 - Switch S2 into ON position
 - USB
 - There are three ways to power the starter kit via USB
 - Set jumpers JP75 and JP77 to position 2-3
 - Set jumper JP76 according to the desired power source:

JP76	Power source	Connector
1-2	USB Device	X12
3-4	DEBUG	X2
5-6	JTAG (ensure that adapter can provide enough current for your application! Some JTAG probes source insufficient power and some features might misbehave unexpectedly)	J14



- For CAN2 (CAN FD), external power supply must be used, not USB

The Hardware – Connectors





Connectors SK-FM4-216-ETHERNET

Number	Description
J1	MCU pins 163..216
J2	MCU pins 1..54
J3	VCCin (1: before switch, 2: after switch)
J4	MCU pins 55..108
J5	MCU pins 109..162
J6	4x GND
J7	2x 5V
J8	2x 3V3
J9	Multicon 0
[J10]	Multicon 0 optional
J11	Multicon 1
[J12]	Multicon 1 optional
J13	Trace
J14	JTAG
J15	Motor drive interface
J16	Motor I/F: Optional signals
J17	Hall Sensors
J18	QPRC
[J19]	Display RGB888 connector
[J20]	FPC/FCC connector


Number	Description
X1	DCin 9..24V
X2	Debug
X3	Ethernet
X4	CAN0
X5	Audio line out
X6	Audio headphones out
X7	CAN1
X8	Audio microphone in
X9	Audio line in
X10	CAN2 (CAN FD)
X11	USB Host (0/1)
X12	USB Device
X13	SD Card Connector

Jumper Settings – (Top Side)

Regular Jumper


Solder Jumper

■ ■ ■ : default position



Jumper Settings – (Bottom Side)

Solder
Jumper





Jumper Settings SK-FM4-216-ETHERNET

Number	Description	Special Type	Default
JP1	USBVCC0	Solder Jumper	Closed
JP2	USBVCC1	Solder Jumper	Closed
JP3	ETHVCC	Solder Jumper	Closed
JP4	MCUVCC		Closed
JP5	USB/UART programming		Closed
JP6	X0A Access	Solder Jumper	Closed
JP7	X1A Access	Solder Jumper	Closed
JP8	AVRH		Closed
JP9	AVCC		Closed
JP10	AVRL		Closed
JP11	X0 Access	Solder Jumper	Open
JP12	X1 Access	Solder Jumper	Open
JP13	VBAT		Closed
JP14	Multicon0: SCL pull-up	Solder Jumper	Open
JP15	Multicon0: SDA pull-up	Solder Jumper	Open
JP16	Multicon1: SCL pull-up	Solder Jumper	Open
JP17	Multicon1: SDA pull-up	Solder Jumper	Open
JP18	DBG Prog (S/W upgrade U2)		Open

Number	Description	Special Type	Default
JP19	MFS0_SOT	Solder Jumper	Closed
JP20	MFS0_SIN	Solder Jumper	Closed
JP21	EthPHY IRQ	Solder Jumper	Closed
JP22	Supply VCCin from motor		Open
JP23	CAN0GND4	Solder Jumper	Open
JP24	CAN0GND6	Solder Jumper	Open
JP25	CAN0pwr	Solder Jumper	Open
JP26	CAN0RX	Solder Jumper	Closed
JP27	CAN0term	Solder Jumper	Open
JP28	CAN0TX	Solder Jumper	Closed
JP29	LCDRST	Solder Jumper	Closed
JP30	HMISCL	Solder Jumper	Closed
JP31	HMISDA	Solder Jumper	Closed
JP32	LCDBL	Solder Jumper	Closed
JP33	CAN1pwr	Solder Jumper	Open
JP34	CAN1GND4	Solder Jumper	Open
JP35	CAN1GND6	Solder Jumper	Open
JP36	I2SDO	Solder Jumper	Closed



Jumper Settings SK-FM4-216-ETHERNET

Number	Description	Special Type	Default
JP37	I2SDI	Solder Jumper	Closed
JP38	I2SCK	Solder Jumper	Closed
JP39	I2SWS	Solder Jumper	Closed
JP40	CAN1RX	Solder Jumper	Closed
JP41	CAN1term	Solder Jumper	Open
JP42	CAN1TX	Solder Jumper	Closed
JP43	I2SMCLK	Solder Jumper	Closed
JP44	I2SAGND	Solder Jumper	Closed
JP45	CAN2RX	Solder Jumper	Closed
JP46	CAN2TX	Solder Jumper	Closed
JP47	CAN2pwr	Solder Jumper	Open
JP48	CAN2GND4	Solder Jumper	Open
JP49	CAN2GND6	Solder Jumper	Open
JP50	CAN2S	Solder Jumper	Closed
JP51	CAN2C	Solder Jumper	Closed
JP52	CAN2O	Solder Jumper	Closed
JP53	CAN2I	Solder Jumper	Closed
JP54	Touch AN24	Solder Jumper	Closed

Number	Description	Special Type	Default
JP55	Touch AN25	Solder Jumper	Closed
JP56	CANFDBAT	Solder Jumper	Closed
JP57	CAN2termH	Solder Jumper	Open
JP58	CAN2termL	Solder Jumper	Open
JP59	CAN2Wake	Solder Jumper	Closed
JP60	Touch AN26	Solder Jumper	Closed
JP61	Touch AN27	Solder Jumper	Closed
JP62	POWERON		Closed
JP63	Button UP	Solder Jumper	Closed
JP64	Button RIGHT	Solder Jumper	Closed
JP65	Button CENTER	Solder Jumper	Closed
JP66	Button LEFT	Solder Jumper	Closed
JP67	Button DOWN	Solder Jumper	Closed
JP68	Button IRQ	Solder Jumper	Closed
JP69	RP1	Solder Jumper	Closed
JP70	EthPHY XO	Solder Jumper	Closed
JP71	EthPHY XI	Solder Jumper	Closed
JP72	Ethernet Yellow LED	Solder Jumper	Closed



Jumper Settings SK-FM4-216-ETHERNET

Number	Description	Special Type	Default
JP73	I2S48.1k	Solder Jumper	Closed
JP74	USB HCONNX	Solder Jumper	Closed
JP75	1-2: External power supply 2-3: Supply via USB or JTAG	JP75 must equal 77	1-2
JP76	1-2: USB Device (X11) 3-4: Debug port (X2) 5-6: JTAG (J11) (watch voltage!)	Only relevant if JP75 and JP77 set to 2-3	3-4
JP77	1-2: External power supply 2-3: Supply via USB or JTAG	JP75 must equal 77	1-2
JP78	SD_CD: 1-2: CD 2-3: CD/DAT3	Solder Jumper	1-2
[JP79]	Backlight enable		Open
[JP80]	Backlight dimming		Open
[JP81]	LCD power control		1-2



Pin-List SK-FM4-216-ETHERNET (3/9)

Pin	Function	Description
1	VCC	MCUVCC
2	PA0 /RTO20_0/TIOA8_0/AIN2_0/INT00_0/MADATA00_0	Pushbutton UP
3	PA1 /RTO21_0/TIOA9_0/BIN2_0/MADATA01_0	Pushbutton RIGHT
4	PA2 /RTO22_0/TIOA10_0/ZIN2_0/MADATA02_0	Pushbutton CENTER
5	PA3 /RTO23_0/TIOA11_0/MADATA03_0	Pushbutton LEFT
6	PA4 /RTO24_0/TIOA12_0/MADATA04_0	Pushbutton DOWN
7	PA5/SIN1_0/RTO25_0/TIOA13_0/ INT01_0 /MADATA05_0	Pushbutton IRQ
8	PA6/SOT1_0/DTT12X_0/MADATA06_0	
9	PA7/SCK1_0/IC20_0/MADATA07_0	
10	P50/SCS72_0/ RTO00_1 /TIOA8_2/MADATA16_0	Motor0/MFT0
11	P51/SCS73_0/ RTO01_1 /TIOB8_2/MADATA17_0	Motor0/MFT0
12	P52/ RTO02_1 /TIOA9_2/MADATA18_0	Motor0/MFT0
13	P53/ RTO03_1 /TIOB9_2/MADATA19_0	Motor0/MFT0
14	PA8/SIN7_0/IC21_0/ INT02_0 /WKUP1/MADATA08_0	Ethernet PHY IRQ
15	PA9/SOT7_0/IC22_0/MADATA09_0	
16	PAA /SCK7_0/IC23_0/MADATA10_0	USB (Host1 VBUS enable)
17	PAB/SCS70_0/RX0_0/FRCK2_0/ INT03_0 /MADATA11_0	USB1 Overcurrent IRQ
18	PAC/SCS71_0/TX0_0/ TIOB8_0 /AIN3_0/MADATA12_0	Motor0/QPRC3
19	P54/SIN15_1/ RTO04_1 /TIOA10_2/INT00_2/MADATA20_0	Motor0/MFT0
20	P55/SOT15_1/ RTO05_1 /TIOB10_2/MADATA21_0	Motor0/MFT0
21	P56/SCK15_1/ DTTI0X_1 /TIOB0_1/MADATA22_0	Motor0/MFT0
22	P57/ IC00_1 /TIOB1_1/MADATA23_0	Motor0/IC0
23	PAD/SCK3_0/TIOB9_0/ BIN3_0 /MADATA13_0	Motor0/QPRC3
24	PAE/ADTG_0/SOT3_0/TIOB10_0/ ZIN3_0 /MADATA14_0	Motor0/QPRC3



Pin-List SK-FM4-216-ETHERNET (3/9)

Pin	Function	Description
25	PAF/SIN3_0/TIOB11_0/INT16_0/MADATA15_0	
26	P58/SIN11_1/ IC01_1 /TIOB2_1/INT02_2/MADATA24_0	Motor0/IC0
27	P59/SOT11_1/ IC02_1 /TIOB3_1/MADATA25_0	Motor0/IC0
28	P5A/SCK11_1/IC03_1/TIOB4_1/MADATA26_0	
29	P5B/FRCK0_1/TIOB5_1/MADATA27_0	
30	P08/SIN14_0/TIOB12_0/INT17_0/MDQM0_0	
31	P09/SOT14_0/TIOB13_0/INT18_0/MDQM1_0	
32	P0A/ADTG_1/SCK14_0/AIN2_1/MCLKOUT_0	
33	P5C/ TIOA11_2 /MADATA28_0/RTCCO_1/SUBOUT_1	Motor0 OPT1 (Brake)
34	P30/RX0_1/TIOA13_2/INT03_2/MDQM2_0/ I2SDI_0	I2S serial receive data input pin
35	P31/TX0_1/TIOB13_2/MDQM3_0/ I2SCK_0	I2S bit clock terminal
36	P32/BIN2_1/INT19_0/ S_DATA1_0	SD I/F
37	P33/FRCK0_0/ZIN2_1/ S_DATA0_0	SD I/F
38	P34/IC03_0/INT00_1/ S_CLK_0	SD I/F
39	VCC	MCUVCC
40	VSS	GND
41	P35/IC02_0/INT01_1/ S_CMD_0	SD I/F
42	P36/IC01_0/INT02_1/ S_DATA3_0	SD I/F
43	P37/IC00_0/INT03_1/ S_DATA2_0	SD I/F
44	P38/ADTG_2/DTTI0X_0/ S_WP_0	SD I/F
45	P39/SIN2_1/RTO00_0/TIOA0_1/AIN3_1/INT16_1/ S_CD_0 /MAD24_0	SD I/F
46	P3A/SOT2_1/RTO01_0/TIOA1_1/BIN3_1/INT17_1/MAD23_0	
47	P3B/SCK2_1/RTO02_0/TIOA2_1/ZIN3_1/INT18_1/MAD22_0/MNACLE_0	
48	P3C/SIN13_0/RTO03_0/TIOA3_1/INT19_1/MAD21_0/MNCLE_0	



Pin-List SK-FM4-216-ETHERNET (3/9)

Pin	Function	Description
49	P3D/SOT13_0/RTO04_0/TIOA4_1/MAD20_0/MNWEX_0	
50	P3E/SCK13_0/RTO05_0/TIOA5_1/MAD19_0/MNREX_0	
51	P5D/SIN10_1/TIOB11_2/INT01_2/MADATA29_0/ I2SMCLK_0	I2S External clock terminal
52	P5E/SOT10_1/TIOA12_2/MADATA30_0/ I2SDO_0	I2S serial transmit data output pin
53	P5F/SCK10_1/TIOB12_2/MADATA31_0/ I2SWS_0	I2S frame sync signal terminal
54	VSS	GND
55	VCC	MCUVCC
56	P40/SIN3_1/RTO10_0/ TIOA0_0 /AIN0_0/INT23_0/MCSX7_0	TFT Connector (CSYNC)
57	P41/SOT3_1/RTO11_0/ TIOA1_0 /BIN0_0/MCSX6_0	TFT Connector (DE)
58	P42/SCK3_1/RTO12_0/ TIOA2_0 /ZIN0_0/MCSX5_0	TFT Connector (DCLK)
59	P43/SIN15_0/RTO13_0/ TIOA3_0 /INT04_0/MCSX4_0	TFT Connector (VSYNC)
60	P44/SOT15_0/RTO14_0/ TIOA4_0 /MCSX3_0	TFT Connector (HSYNC)
61	P45/SCK15_0/RTO15_0/ TIOA5_0 /MCSX2_0	TFT Connector (LEDCTRL)
62	C	C
63	VSS	GND
64	VCC	MCUVCC
65	P4A/ SIN12_1 /AIN0_1/INT04_2	CAN FD control SPI
66	P4B/ SOT12_1 /BIN0_1	CAN FD control SPI
67	P4C/ SCK12_1 /ZIN0_1	CAN FD control SPI
68	P4D/SCS72_1/ RX2_2 /INT05_2	CAN2 (CAN-FD)
69	P4E/SCS73_1/ TX2_2	CAN2 (CAN-FD)
70	P7D /SCK1_1/RX2_0/DTTI1X_0/INT05_0/WKUP2/MCSX1_0	CAN FD Wake
71	P7E /ADTG_7/TX2_0/FRCK1_0/MCSX0_0	CAN FD control SPI
72	INITX	Reset



Pin-List SK-FM4-216-ETHERNET (4/9)

Pin	Function	Description
73	P46/ X0A	[Crystal (Subclock)]
74	P47/ X1A	[Crystal (Subclock)]
75	VBAT	VBAT
76	P48/VREGCTL	
77	P49/VWAKEUP	
78	PF0/SCS63_0/RX2_1/FRCK1_1/TIOA15_1/INT22_1	
79	PF1/SCS62_0/TX2_1/TIOB15_1/INT23_1	
80	P70/ADTG_8/SIN1_1/INT06_0/MRDY_0/CECO_0	
81	P71/SOT1_1/MAD00_0	
82	P72/SIN9_0/TIOB0_0/INT07_0/MAD01_0	
83	P73/SOT9_0/TIOB1_0/MAD02_0	
84	P74/SCK9_0/TIOB2_0/MAD03_0	
85	PF2/RTO10_1/TIOA6_1/MRASX_0	
86	PF3/RTO11_1/TIOB6_1/INT05_1/MCASX_0	
87	PF4/RTO12_1/TIOA7_1/INT06_1/MSDWEX_0	
88	PF5/RTO13_1/TIOB7_1/INT07_1/MCSX8_0	Multicon0 Reset
89	PF6/RTO14_1/TIOA14_1/ INT20_1 /MSDCKE_0	Multicon0 (GINT)
90	PF7/RTO15_1/TIOB14_1/ INT21_1 /MSDCLK_0	Multicon0 (TINT)
91	P75/ SIN8_0 /TIOB3_0/AIN1_0/INT20_0/MAD04_0	Multicon0
92	P76/ SOT8_0 /TIOB4_0/BIN1_0/MAD05_0	Multicon0
93	P77/ SCK8_0 /TIOB5_0/ZIN1_0/MAD06_0	Multicon0
94	PF8/SCS70_1/DTTI1X_1/AIN1_1	
95	PF9/SCS71_1/IC10_1/BIN1_1	
96	P78/SIN6_0/IC10_0/INT21_0/MAD07_0	



Pin-List SK-FM4-216-ETHERNET (5/9)

Pin	Function	Description
97	P79/SOT6_0/IC11_0/MAD08_0	
98	P7A/SCK6_0/IC12_0/MAD09_0	
99	P7B/DA1/SCS60_0/IC13_0/INT22_0	---
100	P7C/DAO/SCS61_0/INT04_1	---
101	PFA/SCK7_1/IC11_1/ZIN1_1	
102	PFB/SOT7_1/IC12_1/INT07_2	
103	PFC/SIN7_1/IC13_1/INT06_2	
104	PE0/ MD1	MD1
105	MD0	MD0/ USB Direct Flash
106	PE2/ X0	Crystal (mainclock)
107	PE3/ X1	Crystal (mainclock)
108	VSS	GND
109	VCC	MCUVCC
110	AVCC	AVCC
111	AVSS	AVSS
112	AVRL	AVRL
113	AVRH	AVRH
114	P10/ AN00 /SIN10_0/TIOA0_2/AINO_2/INT08_0	Motor0/ADC
115	P11/ AN01 /SOT10_0/TIOB0_2/BINO_2	Motor0/ADC
116	P12/ AN02 /SCK10_0/TIOA1_2/ZINO_2	Motor0/ADC
117	P13/ AN03 /SIN6_1/RX1_1/INT25_1	Motor0/ADC
118	P14/ AN04 /SOT6_1/TX1_1	Motor0/ADC
119	PB8 /ADTG_6/SCS63_1/INT08_2/TRACED8	TFT Connector
120	PB9 /SIN9_1/AIN2_2/INT09_2/TRACED9	TFT Connector



Pin-List SK-FM4-216-ETHERNET (6/9)

Pin	Function	Description
121	PBA/SOT9_1/BIN2_2/TRACED10	TFT Connector
122	PBB/SCK9_1/ZIN2_2/TRACED11	TFT Connector
123	P15/ AN05 /SIN11_0/TIOB1_2/AIN1_2/INT09_0	Motor0/ADC
124	P16/ AN06 /SOT11_0/TIOA2_2/BIN1_2	Motor0/ADC
125	P17/ AN07 /SCK11_0/TIOB2_2/ZIN1_2	Motor0/ADC
126	PB0 /AN16/SCK6_1/TIOA9_1	TFT Connector
127	PB1 /AN17/SCS60_1/TIOB9_1/INT08_1	TFT Connector
128	PB2 /AN18/SCS61_1/TIOA10_1/INT09_1	TFT Connector
129	PB3 /AN19/SCS62_1/TIOB10_1	TFT Connector
130	P18/ AN08 /SIN2_0/TIOA3_2/INT10_0	Motor0/ADC
131	P19/AN09/SOT2_0/TIOB3_2/INT24_1/ TRACECLK	TRACE
132	P1A/AN10/SCK2_0/TIOA4_2/ TRACED0	TRACE
133	P1B/AN11/SIN12_0/TIOB4_2/INT11_0/ TRACED1	TRACE
134	P1C/AN12/SOT12_0/TIOA5_2/ TRACED2	TRACE
135	P1D/AN13/SCK12_0/TIOB5_2/ TRACED3	TRACE
136	VSS	GND
137	VCC	MCUVCC
138	PB4 /AN20/SIN8_1/TIOA11_1/INT10_1/TRACED4	TFT Connector
139	PB5 /AN21/SOT8_1/TIOB11_1/INT11_1/TRACED5	TFT Connector
140	PB6 /AN22/SCK8_1/TIOA12_1/TRACED6	TFT Connector
141	PB7 /AN23/TIOB12_1/TRACED7	TFT Connector
142	P1E/ AN14 /TIOA8_1/INT26_1/MAD10_0	Variable Resistor RP1
143	P1F/AN15/RTS5_0/TIOB8_1/INT27_1/MAD11_0	
144	P2A/ AN24 /CTS5_0/MAD12_0	Software Touch



Pin-List SK-FM4-216-ETHERNET (7/9)

Pin	Function	Description
145	P29/ AN25 /SCK5_0/MAD13_0	Software Touch
146	P28/ AN26 /SOT5_0/MAD14_0	Software Touch
147	P27/ AN27 /SIN5_0/INT24_0/MAD15_0	Software Touch
148	PBC /TX1_2/TRACED12	TFT Connector
149	PBD /SCK0_1/RX1_2/AIN3_2/INT10_2/TRACED13	TFT Connector
150	PBE /SOT0_1/BIN3_2/TRACED14	TFT Connector
151	PBF /SIN0_1/ZIN3_2/INT11_2/TRACED15	TFT Connector
152	P26/ TX1_0 /MAD16_0	CAN1
153	P25/AN28/ RX1_0 /INT25_0/MAD17_0	CAN1
154	P24/AN29/ TIOA13_1 /MAD18_0	LCD Illumination Dimming
155	P23 /UHCONX1/AN30/SCK0_0/TIOB13_1	LCD Reset
156	P22/AN31/ SOT0_0 /INT26_0	UART/(USB-serial)
157	P21/ADTG_4/ SIN0_0 /INT27_0/CROUT_0	UART/(USB-serial)
158	P20/NMIX/WKUP0	---
159	USBVCC1	USBVCC1
160	P82/ UDM1	USB
161	P83/ UDP1	USB
162	VSS	GND
163	VCC	MCUVCC
164	P00/ TRSTX	JTAG
165	P01/ TCK /SWCLK	JTAG
166	P02/ TDI	JTAG
167	P03/ TMS /SWDIO	JTAG
168	P04/ TDO /SWO	JTAG



Pin-List SK-FM4-216-ETHERNET (8/9)

Pin	Function	Description
169	P90/INT12_1/Q_IO3_0	QSPI Memory
170	P91/SIN5_1/INT13_1/Q_IO2_0	QSPI Memory
171	P92/SOT5_1/INT14_1/Q_IO1_0	QSPI Memory
172	P93/SCK5_1/INT15_1/Q_IO0_0	QSPI Memory
173	P94/CTS5_1/Q_SCK_0	QSPI Memory
174	P95/RTS5_1/Q_CS0_0	QSPI Memory
175	P96/RX0_2/INT12_2/Q_CS1_0	CAN0
176	P97/TX0_2/INT13_2/Q_CS2_0	CAN0
177	PC0/E_RXER	Ethernet
178	PC1/TIOB6_0/E_RX03	Ethernet
179	PC2/TIOA6_0/E_RX02	Ethernet
180	PC3/TIOB7_0/E_RX01	Ethernet
181	PC4/TIOA7_0/E_RX00	Ethernet
182	PC5/TIOB14_0/E_RXDV	Ethernet
183	PC6/TIOA14_0/E_MDIO	Ethernet
184	PC7/INT13_0/E_MDC/CROUT_1	Ethernet
185	PC8/E_RXCK_REFCK	Ethernet
186	PC9/TIOB15_0/E_COL	Ethernet
187	PCA/TIOA15_0/E CRS	Ethernet
188	ETHVCC	Ethernet
189	VSS	GND
190	PCB/INT28_0/E_COUT	Ethernet Clock Out Option



Pin-List SK-FM4-216-ETHERNET (9/9)

Pin	Function	Description
193	PCE/SIN4_1/INT15_0/ E_TX03	Ethernet
194	PCF/RTS4_1/INT12_0/ E_TX02	Ethernet
195	PDO/INT30_1/ E_TX01	Ethernet
196	PD1/INT31_1/ E_TX00	Ethernet
197	PD2/CTS4_1/FRCK2_1/ E_TXEN	Ethernet
198	P6E /ADTG_5/SCK4_1/IC23_1/INT29_0/E_PPS	Yellow LED on Ethernet connector
199	P6D/ SCK14_1 /IC22_1/TIOB6_2	HMI SCL
200	P6C/ SOT14_1 /IC21_1/TIOA6_2	HMI SDA
201	P6B/SIN14_1/IC20_1/TIOB7_2/ INT14_2	USB0 Overcurrent IRQ
202	P6A /DTT12X_1/TIOA7_2	Ethernet PHY Reset
203	P69 /RTO20_1/TIOB14_2	Multicon1 Reset
204	P68/ SCK13_1 /RTO21_1/TIOA14_2	Multicon1
205	P67/ SOT13_1 /RTO22_1/TIOB15_2	Multicon1
206	P66/ SIN13_1 /RTO23_1/TIOA15_2/INT15_2	Multicon1
207	P65/RTO24_1/ INT28_1	Multicon1 (GINT)
208	P64/CTS4_0/RTO25_1/ INT29_1	Multicon1 (TINT)
209	P63 /ADTG_3/RTS4_0/INT30_0/MOEX_0	USB (Host/Device Switch)
210	P62 /SCK4_0/MWEX_0	USB (Host0 VBUS enable)
211	P61 /UHCONX0/SOT4_0/MALE_0/RTCC0_0/SUBOUT_0	USB
212	P60 /SIN4_0/INT31_0/WKUP3/CEC1_0	USB Direct Flash / DEVICE_VBUS
213	USBVCC0	USBVCC0
214	P80/UDMO	USB



- The assembled CAN FD transceiver is specified only up to 2 Mbits/sec whereas the FM4's hardware supports up to 5 Mbits/sec
 - If a specified 5 Mbits/sec transceiver for CAN FD (CAN2) is needed, the 8 pin device TJA1044 can be soldered into the 14 pin footprint of the 2 Mbits/sec TJA1145
 - Small software modification necessary
 - ◆ Configure pin P7E as GPIO output
 - ◆ Drive pin P7E low
- On a production lot with Spansion branding following errors on the silkplot have been found:
 - JP5 is labeled USB PROG but must be UART PROG
 - The naming labels of RN14 and RN15 near the SD card connector are swapped, there is no electrical problem though
 - Both errors are rectified on all boards with Cypress branding



Software


Software Examples



- Software examples for IAR EWARM V6.60 or KEIL µVision5.1:

See <drive:>\Examples\ or www.spansion.com

- [s6e2cc_template-v14.zip](#)
 - ◆ ‘Empty’ project as base for user applications
- [s6e2cc_ethernet_driver-v16.zip](#)
 - ◆ Spansion low-level Ethernet driver
- And [several more](#)



Note: Please copy the examples to your local drive before compiling!

You can find product information of the
commercially supported TCP/IP stack by [SEVENSTAX on this CD.](#)





- The following software tools are available
 - USB Virtual-COM port
 - ◆ allows UART communication via the PC's USB connection
 - ◆ On-board UART-to-USB converter (via X2, CMSIS-DAP)
 - ◆ For driver installation <drive:>[\drivers\driverinstaller.exe](#)
 - FLASH USB DIRECT Programmer
 - ◆ Microcontroller Flash programming (via X12, USB-Device-Port)
 - ◆ Install from <drive:>[\tools\USBDIRECT](#)
 - Terminal program ,Serial Port Viewer
 - ◆ Install from <drive:>[\tools\serialportviewer\setup.exe](#)



Flash Programming



- There are several options to program the microcontroller's flash:
 - FLASH USB DIRECT Programmer via X12 (USB device)
 - ◆ For installation <drive:>\tools\USBDIRECT\setup.exe
 - ◆ USB driver is located in subdirectory of FLASH USB DIRECT Programmer
 - FLASH MCU Programmer via X2 (Serial via DEBUG USB/Serial bridge)
 - ◆ For installation <drive:>\tools\PCWFM3-V01L07\setup.exe
 - ◆ For driver installation of USB/Virtual-COM port
<drive:>\drivers\driverinstaller.exe
 - JTAG Programming via X2 (CMSIS-DAP)
 - ◆ Example is given for IAR and KEIL
 - ◆ See documentation of your development suite how to setup CMSIS-DAP
 - JTAG Programming via J14 (optional JTAG adapter)
 - ◆ The correct JTAG-adapter must be selected in the IDE toolchain

Flash Programming via X12 (USB direct)



FLASH USB DIRECT Programming via X12 (USB device)

- Jumper Setting

- ◆ Select the MCU power supply (JP75, 76, 77)
- ◆ Open JP5 (USB PROG)
- ◆ Set switch S1 to position PGM


- Connect USB port X12 with the PC

- If connected for first time Windows OS may ask for a driver

- ◆ See subfolder 'driver' of USBdirect installation path
or use <drive:>\drivers\driverinstaller.exe

- Start the FLASH USB DIRECT Programmer

- ◆ For first installation: <drive:>\Utilities\USBDIRECT\setup.exe
- ◆ Select the COM port
- ◆ Press Reset
- ◆ Start Full Operation
- ◆ Set switch S1 to position RUN
- ◆ Press Reset




Flash Programming via X12 (USB device)



- Select the correct target MCU: S6E2CCAH0A/J0A/L0A
- Browse for the programming file (*.srec or *.hex)
 - IAR: see subfolder <project>\example\IAR\output\release\exe
 - ARM/KEIL: see subfolder <project>\example\ARM\output\release
- Adjust the corresponding virtual COM-port

Select MCU: S6E2CCAH0A/J0A/L0A
Select file (*.srec; *.hex)
Select Virtual COM-port



- Use 'Full Operation'
 - Download kernel
 - Erase Flash memory / Blank check
 - Program & Verify project to Flash memory
- Set switch S1 to position RUN and press Reset button


Flash Programming via X2 (Serial)



▪ FLASH MCU Programming via X2 (DEBUG)

- Jumper Setting

- ◆ Select the MCU power supply (JP75, 76, 77)
- ◆ Close JP5
- ◆ Set switch S1 to position PGM



- Connect the board via USB CMSIS-DAP (X2) to the USB-Port of the PC
 - ◆ When connected for first time Windows OS may ask for ,spansionusbvcomm.inf'
 - <drive:>\drivers\cmsis-dap
- Use the FLASH MCU Programmer for FM3/FM4
 - ◆ For installation <drive:>\tools\PCWF M3-V01L07\setup.exe



- Select the correct target MCU: S6E2CCAHOA/J0A/L0A
- Select 4MHz Crystal Frequency
- Browse for the programming file (*.srec or *.hex)
 - IAR: see subfolder <project>\example\IAR\output\release\exe
 - ARM/KEIL: see subfolder <project>\example\ARM\output\release
- Adjust the corresponding virtual COM-port

Select MCU: S6E2CCAHOA/J0A/L0A

Select 4MHz Crystal Frequency

Select file (*.srec / *.hex)

Select Virtual COM-port

Execute 'Full Operation'


incl. stand-alone operations

- Download Kernel

- Erase

- Blank Check

- Program&Verify




- Set switch S1 to position RUN and press Reset button



JTAG Debugger



- This starterkit includes an on-board JTAG adapter
 - Compatible to CMSIS-DAP
http://www.keil.com/support/man/docs/dapdebug/dapdebug_introduction.htm
 - Select debugger CMSIS-DAP in your tool chain
- Any other JTAG-adapter can be connected to J14, too.
 - The correct JTAG-adapter must be selected in the IDE toolchain
 - ◆ No jumper setting is required
- Additional virtual COM port is provided by X2 (DEBUG)
 - ◆ For driver installation <drive:>\drivers\driverinstaller.exe




Setup in IAR EWARM (1)

- Navigate to project options:


- Via Files-List

- ◆ Right-click at the project
 - ◆ Select „Options...“




- Or via menu „Project“

- ◆ Select „Options...“




Setup in IAR EWARM (2)

- Setup Project Debugger Options
 - (1) Navigate to Debugger
 - (2) Select tab „Setup“
 - (3) Select Driver „CMSIS-DAP“



- (4) Select in „CMSIS-DAP“
- (5) Select tab „JTAG/SWD“
- (6) Select SWD






Setup in Keil µVision (1)



- Navigate to project options:


- Via Project

- ◆ Right-click at the project
 - ◆ Select „Options...“




- Or via menu „Project“

- ◆ Select „Options...“



Setup in Keil µVision (2)

- Setup Debug & Utilities
 - (1) Select tab „Debug“
 - (2) Select „CMSIS-DAP Debugger“



- (3) Select tab „Utilities“
- (4) Select „CMSIS-DAP Debugger“



Please see instructions contained in firmware update package!


IAR Embedded Workbench

- Installation
- Getting Started
- Open Project
- Build Project
- Debug Project





- Install EWARM from IAR-CD or download latest version from IAR Website
 - EWARM size-limited (32k) or time-limited (full) Evaluation Version
 - ◆ <http://supp.iar.com/Download/SW/?item=EWARM-EVAL>
- Start EWARM Workbench
- Choose File → Open → Workspace
 - e.g.: <drive:>\sw-examples\




IAR Workbench – Main Window




■ IAR Workbench

- Workspace on left side of Workbench window
 - ◆ If hidden then View→Workspace
- Source files on right side of Workbench window as tabbed windows
- Project open
File → Open → Workspace → *.eww
- For new projects
start with ,mb9bfd1xt_template'






- IAR Menu Bar



IAR Workbench – Workspace



■ IAR Workspace Window






- Making the Project

- Use Make-Icon (), <F7> or
Menu: Project→Make
- Check for no errors in Output window
below
- Build errors are indicated by or
In Output window and Source view







- Download to Target and Start Debugging
 - Use  Icon, <Ctrl>-D, or Project→Download and Debug
 - A new menu bar will occur on sucessful connection to target






▪ Source Window

- The Source windows do not change contents but get additional information
 - ◆ Current line (PC):

 - ◆ Halted on Breakpoint:

 - ◆ Halted on Data break (example):


▪ Disassembly Window

- Shows ‘pure’ disassembly view
- Shows mixed mode view



```
Disassembly
Go to | Memory | 
0x1ffffc3bc: 0x6001      STR    r1, [r0]
if(!BUT_PDIR&PSW2)
??main_4:
0x1ffffc3be: 0x4824      LDR.N  r0, ??DataTable10_33 [0x1ffffc450] ; PDIR5
0x1ffffc3c0: 0x6800      LDR    r0, [r0]
0x1ffffc3c2: 0x0780      ISLS   r0, r0, #30
0x1ffffc3c4: 0xd4dc      BMI.N ?main_2           ; 0x1ffffc380
    Timer1Control_bit.TimerEn = 1;
0x1ffffc3c6: 0x4821      LDR.N  r0, ??DataTable10_32 [0x1ffffc44c] ; Timer1Control
0x1ffffc3c8: 0x6800      LDR    r0, [r0]
0x1ffffc3ca: 0xf050      ORRS.W r0, r0, #128     ; 0x80
```



- Watch Window

- Watch

- ◆ Expressions/Variables have to be added by user and are updated by Halt/Breakpoint

Expression	Value	Location	Type
Tmr1Tick	0	0x20000804	int
[...]			

Watch Locals Statics Auto Live Watch Quick Watch

- Quick Watch

- ◆ The Quick watch allows the user to calculate and recalculate expressions even with variables

Quick Watch			
Expression	Value	Location	Type
<input type="text" value="Q"/> Tmr1Tick + 0xAA - 123			
Tmr1Tick + 0xAA - 123	0x00000030		int


Watch Locals Statics Auto Live Watch Quick Watch

- ◆ The drop down menu memorizes the last typed contents



▪ Simulator

- Mark Project File in Workspace
- Choose Project→Options
- Choose Simulator in Debugger Setup
- Start Simulator with usual Icon



KEIL µVision

- Installation
- Getting Started
- Open Project
- Build Project
- Debug Project






- Install µVision from KEIL-CD or download latest version from KEIL Website
 - Evaluation Version
 - ◆ <https://www.keil.com/demo/eval/arm.htm>
 - ◆ Registration required
- Install ULINK-ME
 - Special installation is not needed, because ULINK-ME acts as a USB Human Interface Device (HID) and thus needs no extra USB driver
- Install ULINK Pro (optional)
 - ULINK Pro needs an own dedicated USB driver located in:
<Installation Path>\KEIL\ARM\ULINK
- Start µVision




- Choose Menu: Project→Open Project...
 - Browse to: <drive:>\sw-examples\mb9bf56xr_gpio-v10\example\ARM\
 - Choose mb9bf56xr_gpio.uvproj



KEIL µVision – Main Window


■ KEIL µVision

- Project window on left side of IDE window
 - ◆ Choose:
View→Project Window
if hidden
- Source files on right side of IDE window as tabbed windows
- Output window on bottom side of IDE window






- Menu Bar 1
 - Can be moved in bar window area or set floating






- Menu Bar 2
 - Can be moved in bar window area or set floating



KEIL µVision – Project Window

- µVision Project Window






▪ Making the Project


- Use Rebuild Icon
() or
Project→Rebuild all target files

- Check for no errors in Output window below



```
Build Output
Build target 'MB9BF50x Flash'
assembling startup_MB9BF50x.s...
compiling system_MB9BF50x.c...
compiling Blinky.c...
compiling IRQ.c...
compiling Serial.c...
compiling Retarget.c...
linking...
Program Size: Code=2604 RO-data=320 RW-data=32 ZI-data=512
".\Flash\Blinky.axf" - 0 Error(s), 0 Warning(s).
```

- Build errors are shown in Output window.
 - ◆ Can be double-clicked by showing the source line with a blue arrow



The screenshot shows the KEIL µVision IDE interface. At the top, there's a code editor window displaying C code. In the middle, a 'Build Output' window is open, showing the results of a build. A specific error is highlighted in the output window: 'Blinky.c(104): error: #20: identifier "TYPO" is undefined'. Below the code editor, there's a toolbar with several icons, including a magnifying glass and a double arrow.

```
stdio.h
rt_misc.h
TYPO while (1) {
    /* Loop forever
}
compiling Blinky.c...
Blinky.c(104): error: #20: identifier "TYPO" is undefined
Blinky.c:    TYPO while (1) { /* Loop forever
Blinky.c:        ^

```



- Start Debugging

- Download to target first, when MCU Flash does not contain the current application openend and built in the IDE

- ◆ Use Download Icon () or Menu: Flash→Download

- Start Debug Session


- ◆ Use Start/Stop Debug Icon () or Menu: Debug→Start/Stop Debug Session

- Ending Debug Session

- ◆ Use same way as for starting debug session




- Debugging Icon Bar
 - During a Debug Session there will be visible a new icon bar





- Source View

- The Source windows do not change contents but get additional information





- Disassembly View
 - Mixed mode is selectable and deselectable

The diagram illustrates the Keil µVision Disassembly View window with four callouts:

- Active Breakpoint:** Points to a red square marker at address 0x0000042E.
- Disabled Breakpoint:** Points to a grey square marker at address 0x00000432.
- Current Program Counter:** Points to a white square marker at address 0x00000436.
- Current Cursor Line of Code highlighted in yellow background (Yellow Box):** Points to a yellow square marker at address 0x00000438.


Disassembly Window Content:

Address	OpCode	Instruction	Comment
0x0000042A	F7FFFFA3	BL.W	LED_i:
101:	ADC_init();		
0x0000042E	F7FFFF67	BL.W	ADC_i:
102:	SER_init();		
103:			
0x00000432	F000F8AE	BL.W	SER_i:
104:	while (1) {		
105:			
0x00000436	E015	B	0x00000436
106:	AD_value = AD_last;		
→0x00000438	4816	LDR r0,[p]	
0x0000043A	8804	LDRH r4,[r]	
107:	if (AD_value != AD_last		




▪ Memory Window

- Up to 4 Memory windows can be displayed in tabs
- Memory is updated during runtime
- Memory window tabs are shared with Watch windows



▪ Register View

- Register view is a tab of the Project window
- Changes are highlighted in dark blue text background
- Register tree knots can be expanded





- Variable Windows

- Watch Windows

- ◆ Up to 2 Watch windows are sharing their tabs with e.g. Memory and Local views
 - ◆ Updated during runtime
 - ◆ Any changes are highlighted in dark blue text background color
 - ◆ Displayed values can be changed by user during break

Watch 1	
Name	Value
\Blinky\AD_dbg	0x01EA

Locals Watch 1 Memory 1

- Local View

- ◆ The local view shares the tab with e.g. Memory and Watch windows
 - ◆ Any changes are highlighted in dark blue text background color
 - ◆ Displayed values can be changed by user during break

Locals	
Name	Value
AD_value	0x01EA
AD_print	0x01EA
ticks	

Locals Watch 1 Memory 1




- Trace via ITM
 - Simple Trace views via Instrumentation Trace Macro is supported by µLINK ME
 - ◆ Records
 - ◆ Exceptions
 - ◆ Counters

Type	Ovf	Num	Address	Data	PC	Dly	Cycles	Time[s]
ITM		0		41H			82975148	1.03718935
ITM		0		44H			82975293	1.03719116
ITM		0		20H		X	82988592	1.03735740
ITM		0		76H		X	82988592	1.03735740
ITM		0		61H		X	82988592	1.03735740
ITM		0		6CH		X	82988592	1.03735740
ITM		0		75H		X	82988592	1.03735740
ITM		0		65H		X	82988592	1.03735740
ITM		0		20H		X	82988592	1.03735740
ITM		0		3DH		X	82988592	1.03735740
ITM		0		20H		X	82988592	1.03735740
ITM		0		30H		X	82988592	1.03735740
ITM		0		78H		X	82988592	1.03735740
ITM		0		30H			82993831	1.03742289
ITM		0		31H		X	83001392	1.03751740
ITM		0		45H		X	83001392	1.03751740
ITM		0		42H		X	83001392	1.03751740
ITM		0		0DH		X	83001392	1.03751740
ITM		0		0AH		X	83001392	1.03751740
ITM		0		0DH		X	83001392	1.03751740



- Trace via ETM
 - Check settings in menu:
Flash→Configure Flash Tools... Tab:Debug





■ Instruction Trace

- Real Time Trace recording
- Output can be filtered by several ETM and ITM events
- Trace buffer is held in PC memory and transferred to µVision on break

Instruction Trace

#	Type	Flag	Num	PC	Opcode	Instruction	Source Code
1048564	ETM			0x0000043E	4284	CMP r4,r0	
1048565	ETM			0x00000440	D001	BEQ 0x00000446	
1048566	ETM			0x00000446	42AC	CMP r4,r5	111: if (AD_value != AD_print) { /* Make sure that AD inter
1048567	ETM			0x00000448	D002	BEQ 0x00000450	
1048568	ETM			0x00000450	4814	LDR r0,[pc,#80] ; @0x000004A4	116: if (clock_1s) {
1048569	ETM			0x00000452	7800	LDRB r0,[r0,#0x00]	

Blinky.c Abstract.txt stdio.h

```


108     if (AD_value != AD_last)          /* Make sure that AD interrupt did    */
109         AD_value = AD_last;           /* not interfere with value reading */
110
111     if (AD_value != AD_print) {      /* Make sure that AD interrupt did    */
112         AD_print = AD_value;        /* Get unscaled value for printout   */
113         AD_dbg   = AD_value;

```



▪ Simulator

- The Core Simulator can be selected by the menu:
Flash → Configure Flash Tools... and then choosing Use Simulator
- Look & feel is like using ULINK debugger
- Controllable also with *.ini files





Finally

Workshops & Seminars



FM3/FM4 Seminar	Motor Control	USB Workshop	Ethernet Workshop
Please register here: http://news.spansion.com/seminars			
<ul style="list-style-type: none"> • Overview FM3/FM4 family <ul style="list-style-type: none"> • Memory • Peripheral resources • Packages • Processor architecture <ul style="list-style-type: none"> • Bus structure • Flash memory • Flash programming • Peripheral resources <ul style="list-style-type: none"> • Clock distribution • Timer • Interfaces • FM3 features • Development tool chains <ul style="list-style-type: none"> • IAR workbench / J-Link • KEIL µVision / uLink • Starter Kits • Practical exercises <ul style="list-style-type: none"> • Flash programming • Project setup/modification • Debugging • External interrupts 	<ul style="list-style-type: none"> • Introduction of Spansion MCU <ul style="list-style-type: none"> • Line-up of microcontrollers with motion control features • Performance • Introduction of motors types <ul style="list-style-type: none"> • ACIM • BLDC • PMSM • Introduction of control types <ul style="list-style-type: none"> • Sinusoidal commutation • Field Orientated Control • Space Vector Modulation • Peripherals of FM3/FM4 MCUs <ul style="list-style-type: none"> • Base Timer • Multifunction Timer • 12-bit A/D Converter • Quadrature Position and Revolution Counter • Interrupt Controller • Hands-on exercise / SW-Example <ul style="list-style-type: none"> • BLDC motor with hall sensor • PMSM motor with field orientated control 	<ul style="list-style-type: none"> • Introduction of Spansion MCU <ul style="list-style-type: none"> • Line-up of USB MCUs • USB vs. RS232 <ul style="list-style-type: none"> • Historical Background • Electrical Layer • USB Protocol <ul style="list-style-type: none"> • Enumeration Process (Descriptors & USB Settings) • Transfer Types • Data Transfers • USB Class Concept • Software Driver Concepts <ul style="list-style-type: none"> • USB Host • USB Examples <ul style="list-style-type: none"> • Virtual COM Port • USB Descriptor Manager <ul style="list-style-type: none"> • Create Template Classes • Create Descriptors • PC software based on LibUSB • Special Use Cases <ul style="list-style-type: none"> • e.g. boot loader 	<ul style="list-style-type: none"> • Introduction of Spansion MCU <ul style="list-style-type: none"> • Line-up of Ethernet MCUs • Fundamentals of Ethernet • Ethernet Microcontrollers • Hardware Design considerations • Software Design considerations • Communication layer models • The Internet Protocol suite • Web technologies in embedded systems • Developing Ethernet applications <ul style="list-style-type: none"> • Tools and methods • Practical hints and advice on FM3 Ethernet solutions • Hands-on training • Ethernet based industrial automation networks (Fieldbus)



- Please check the following website, for any available updates

www.spansion.com

- Please contact your local support team for any technical question

America: spansion.solutions@spansion.com

China: mcu-ticket-cn@spansion.com

Europe: mcu-ticket-de@spansion.com

Japan: mcu-ticket-jp@spansion.com

Other: <http://www.spansion.com/Support/SES/Pages/Ask-Spansion.aspx>



- Gültig für EU-Länder:
 - Gemäß der Europäischen WEEE-Richtlinie und deren Umsetzung in landesspezifische Gesetze nehmen wir dieses Gerät wieder zurück.
 - Zur Entsorgung schicken Sie das Gerät bitte an die folgende Adresse:
- Valid for European Union Countries:
 - According to the European WEEE-Directive and its implementation into national laws we take this device back.
 - For disposal please send the device to the following address:



**CCS Express GMBH
c/o Spansion International Inc.
Frankfurter Str. 83-107
D-65479 Raunheim
Germany**



- This board is compliant with China RoHS



www.spansion.com

Spansion®, the Spansion logo, MirrorBit®, MirrorBit® Eclipse™ and combinations thereof are trademarks and registered trademarks of Spansion LLC in the United States and other countries. Other names used are for informational purposes only and may be trademarks of their respective owners.

This document is for informational purposes only and subject to change without notice. Spansion does not represent that it is complete, accurate or up-to-date; it is provided "AS IS." To the maximum extent permitted by law, Spansion disclaims any liability for loss or damages arising from use of or reliance on this document.