


**b** 

## Solder Instruction

- 1. Cable should be prepared for soldering. The cable/wires must be pretinned.
- 2. Insert cable/wire into solder cup.
- 3. Operate the soldering iron at 350°C, 50 Watt max . and use a pencil tip.
- 4. Put tip to wire in solder cup.
- 5. After 1 second bring in solder.
- 6. Heat for 3 seconds longer. Do not heat contact more than 4 seconds in total.
- 7. Remove soldering iron.
- 8. Wait until solder gets rigid again.
- 9. Do not solder adjacent contacts consecutively, alternate position within the connector to minimize heat build up.

## RECOMMENDED PANEL CUT-OUT



r SUT GmbH	HAND					tol	erance		scale: 3:1
ED OR AY NOT WITHOUT									material: SEE SHEET 1
IED OR 4AY NO- 7 WITHC CONEC	В							dim. in mm	
COPIED IND MAY ARTY WI	NG						date	name	title:
E COPIED C AND MAY I PARTY WIT	AWI					drawn	01.07.13	Lehmenkühler	PANEL CUT-OUT
NOT BE WAY, A THIRD F N.	D ON TO A THIRD PERMISSION.  IIP AND COPYRIGH  ALTER CAD DR.				appd.	02.07.13	Fischer	D-SUB MALE 37pos. SOLDER CUP	
AY NO ANY V A TH SION.						norm			with threaded lock and 4-40 UNC stud bolt
Z > D Si O						d-old			dwg no: DIN-
WING CED II D ON T		1 x b	Ä4815	02.07.2013	Lehm.		45 =		15K1A1333
IIS DRA EPRODU E PASSE RITTEN WNERSH		a	Original						sh: 2
THIS REPR BE PA WRIT	0	rev.	description	date	name	<b>,</b>	7/1	<b>11-V</b>	part no: SEE SHEET 1

F